S1 60 Mount 417 Donovan Cam Drive Mount Configurations All AVIAID Mounts are Mounting bolt holes must be drilled. integral to pump. No Bolt pattern is indicted on cover with adapters are required. drill points to allow clocking of pump. Separators are .16" or All configurations available. .25" wide. Mount drawings are full size. "Xxxx" indicates hex size in 1/16ths. "xXxx" indicates separator width (1 = .16", 2 = .25", 5 = .50". "xxXX" indicates Mount #.