

S1 63 Mount AR/Sayler Ford
 Accessory Drive Position
 All pump configurations & options available

Mount Configurations
 All AVIAID Mounts are integral to pump. No adapters are required. Separators are .16" or .25" wide. Mount drawings are full size. "Xxxx" indicates hex size in 1/16ths. "xXxx" indicates separator width (1 = .16", 2 = .25", 5 = .50"). "xxXX" indicates Mount #.

